


**MODEL UT8920
Heavy Duty Pneumatic Blind Riveter**





UT8920

Parts List

Ref. No.	Description	Part No.
1	Jaw Housing	9760075
2	Jaw Set (a set of 3)	9760076
3	Jaw Pusher	9760077
4	Jaw Pusher Spring	9760079
5	Jaw Kit (Includes #2, 3, 4)	9760123
6	Jaw Housing Coupler	9760078
7	Nut	9760080
8	Hydraulic Plunger	9760081
9	O-Ring Seal	9760082
10	O-Ring Washer	9760083
11	Screw Plug	9760084
12	Return Spring	9760085
13	X-Ring Seal	9760086
14	X-Ring Seal	9760087
15	Hydraulic Section	+
16	Wiper Ring	9760089
17	Head	9760090
18	3/16" Nosepiece	9760091
*	1/4" Nosepiece	9760092
19	Trigger roll pin	9760115
20	Trigger Arm	9760116
21	Valve Tube	9760114
22	O-Ring	9760128
23	Valve Tube Spring	9760113
24	Valve Plate	9760112
25	Valve Pressure Spring	9760111
26	Inlet Fitting O-Ring	9760099
27	Screw Plug	9760110
28	Throttle Asmbly (#'s 21-27)	9760125

Ref. No.	Description
29	Air Inlet Plug
30	1/4" Air Inlet Fitting
31	O-ring Seal
32	Sealing Washer
33	Rubber Bumper
34	Clip
35	Cylinder Cap
36	O-ring Seal
37	Damping Ring
38	Air Cylinder Body
39	Hydraulic Rod Guide
40	Ring Washer
41	Ring Washer
42	X-Ring Seal
43	Guide Washer
44	Lock Nut
45	Plunger Rod
46	Front Piston Head Disc
47	Piston Head Packing Ring
48	Rear Piston Head Disc
49	Piston Head Spring Washer
50	Piston Head Lock Screw
51	Wrench
52	Plastic Bottle
*	Jaw Seal Kit (Includes #4, 9, 10, 12, 13, 14, 16)
+	Not available as a replacement
*	Not Shown



11

Part No.
9760120
9760118
9760119
9760117
9760126
9760109
9760108
9760107
9760106
+
9760103
9760127
9760093
9760101
9760102
9760100
9760104
9760094
9760095
9860096
9760097
9760098
9760121
9760122
9760124
t part